

**FOG FREE
MIRRORS**

Lee Consultants

Don't get all steamed up!

Before



After



Avoid the frustration of a steamed up mirror after a bath or shower by fitting a Fog Free Mirror heating element. Highly efficient, low power

**FOG FREE
MIRRORS**

requirements and easily fitted to the back of most mirrors. The essential finishing touch to a high quality bathroom.

**Fog Free Mirrors from:
Lee Consultants,
2, Sandringham Drive,
Poynton, Cheshire,
SK12 1JQ
England**

Telephone/Fax: ++44 (0)1625 858500

Email: sales@fogfreemirrors.com

Web Site: www.fogfreemirrors.com